




The 5 component DrySnap system is a snap to install.

Step 1	Step 2	Step 3
		
<p>Screw joist brackets with pitch spacers attached into joist.</p>	<p>Snap starter channel to joist bracket.</p>	<p>Snap panels into place and finish with trim cap.</p>

