

Stops

Lodi Lumber Company

These mouldings are typically used for attaching to a door jamb on both sides and on top of the door jamb where the door comes to rest. They provide covering for the gap that is between the door and the jamb, while also, stopping the door from moving any further.

Stops



P 122
 1 1/16" x 1/2"



M 210
 5/8" x 5/8"



P 93
 5/8" x 3/4"



P 89
 3/4" x 3/4"



M 204
 1/2" x 1 1/8"



N 32
 3/8" x 1 3/8"



N 44
 3/8" x 1 3/8"



N 64
 3/8" x 1 3/8"



M 170
 7/16" x 1 3/8"



M 378
 1/2" x 1 3/8"

S = Stock, mainly Oak & Poplar **N** = Non-stock, subject to stock on hand

Stops



P 78
 3/4" x 1 1/2"



P 95
 3/4" x 1 1/2"



M 175
 1/2" x 1 3/4"



M 93
 1/2" x 1 3/4"



M 215
 3/4" x 1 3/4"



M 97
 1/2" x 1 7/8"



M 98
 1/2" x 1 7/8"



P 41
 1" x 2"

S = Stock, mainly Oak & Poplar **N** = Non-stock, subject to stock on hand

Stops



M 223
5/8" x 2 1/8"



M 46
5/8" x 2 1/8"



P 49
3/4" x 2 1/4"

S = Stock, mainly Oak & Poplar

N = Non-stock, subject to stock on hand